TECHNICAL NOTES: **THREADED MTB** for **SRAM** — Ceramic Bearings





THREADED MTB for SRAM PART LIST

Item #	Part #	Description	QTY Included
1		RIGHT THREADED CUP	1
2		LEFT THREADED CUP	1
3	SB-24X37Z	24X37X7 CERAMIC SEALED BEARING	1 Enduro
4	SB-22X37X8Z	ENDURO GXP 22X37X8 CERAMIC BEARING	1 ceramic
5	24MMSEAL	24MM OUTER SILICONE SEAL	1
6	BB86-GXPSEALL	22MM OUTER SILICONE SEAL FOR GXP	1
7	BB-24MM-0.5Z	0.5MM SHIM FOR 24MM BB SPINDLE	1
	BB-24MM-1.0Z	1MM SHIM FOR 24MM BB SPINDLE	2
8	BB-WAVEWASH-GXP	24MM ID WAVE WASHER	1

Recommended tools:

- Outboard bottom bracket cup tool (Park Tool BBT-69)
- Torque wrench
- Grease



TECHNICAL NOTES: THREADED MTB for SRAM — Ceramic Bearings



IMPORTANT: Thoroughly clean the bottom bracket shell and apply a layer of high quality grease to mating surfaces before installation.

<u>DO NOT use any brand bearing retaining compounds or epoxies during installation, use of which will void any warranty.</u>



1. Thoroughly clean the bottom bracket shell. Apply a thin layer of grease to inner shell.



2. Apply a thin layer of grease to cup.



3. Insert drive side cup and center sleeve into frame, add supplied spacers as necessary to achieve proper bottom bracket width.



4. Use Park Tool BBT-69 to thread drive side cup into frame until flush. Using torque wrench, fully tighten to 35-50Nm.



5. Apply a thin layer of grease to cup.



6. Insert non-drive side cup into frame, add supplied spacers as necessary to achieve proper bottom bracket width.

TECHNICAL NOTES: THREADED MTB for SRAM — Ceramic Bearings





7. Use Park Tool BBT-69 to thread non-drive side cup into frame until flush. Using torque wrench, fully tighten to 35-50Nm.



8. Make sure wave washer and outer dust seal is in place before installing right crank arm.



9. Make suer outer dust seal is in place before installing the left crank arm.



10. Install left crank arm, tighten crank to manufacturer specifications, approximately 48-54Nm. Use crank spacers as needed to take up any play. Remove spacers as necessary if binding occurs.

NOTE: Due to the wide variety of frame manufacturers, Wheels Manufacturing cannot guarantee compatibility with all frames. Please consult with your specific frame manufacturer before installation. Wheels Manufacturing is not responsible for damage done to your frame as a result of installation or use of this product.

IMPORTANT: Wheels Mfg Limited Warranty

Wheels Mfg PressFit components, excluding Enduro bearings are warranted for a period of 2 years. Enduro warrants its 24x37 angular contact bearings and 24x37 ceramic bearings for a period of 1 year to be free of defects in workmanship or materials. Excessive exposure to environmental elements or improper installation or removal voids warranty. Do not wash the bottom bracket area with high-pressure jets of water. Do not remove or install bearings in or out of cups with a hammer! Do not install bearings in cups by pressing on inner bearing race, bearing damage will result. Failure to use proper installation and removal tools will damage bearings and greatly reduce bearing life.